

RENEWAL™ SYSTEM

ever®

The new form of intensive use seating

The Renewal™ replacement cushion system allows you to easily remove and replace the worn or outdated seat cushions on your **ever** chair.



It's easy!

Contact Cramer Customer Care to order your replacement cushions at 800.366.6700.

1. After your cushions arrive, take the Renewal™ Key out of its holder on the underside of the seat cushion.
2. Remove the cushions with a simple quarter turn of the Quick Lock fasteners – two on the seat cushion, four on the back cushion.
3. Place the new cushions on the frame and secure the Quick Lock fasteners.
4. Stand back and admire your 'new' **ever** chair.

* Follow the same instructions to swap cushions between **ever** chairs at your facility.



Congratulations! Your new **ever**[®] chair was designed to last longer and use fewer resources over time.

When you replace your cushions, you can return them to Cramer for recycling. And the materials that make up **ever**'s core – aluminum, plastic, steel – are also recyclable.

For information on how to recycle your **ever** chair, contact Cramer Customer Care at 800.366.6700.



1222 Quebec Street, North Kansas City, Missouri 64116
1.800.366.6700

www.cramerinc.com